



growing
ADVANTAGE
The Almond Conference

Almond Quality: Everything You Want to Know About Retaining Almond Crunch and Flavor

Brian Dunning, Blue Diamond Growers
(Moderator)

Guangwei Huang, ABC (Moderator)

Fanbin Kong, University of Georgia

Alyson Mitchell, UC Davis

Ellie King, National Food Laboratory

Dawn Chapman, National Food Laboratory

Ron Pegg, University of Georgia





Almond Quality: Everything You Want to Know About Retaining Almond Crunch and Flavor

12:30 –2:30pm, December 9, 2014

Room 306-307, Sacramento Convention Center



ABC Almond Quality and Food Safety Program – Four Pillars

- Research
 - Food Safety
 - Almond Quality
- Survey and Monitor
 - Pathogen
 - Pesticide Residues
 - Aflatoxin
 - Heavy Metals:
- Education
 - Annual AQFS Symposium
 - Ongoing Industry Workshops and Seminars
 - Educational Programs
 - Tools and Factsheets
- Program Development + Compliance
 - Annual AQFS Symposium
 - Ongoing Industry Workshops and Seminars
 - Educational Programs
 - Tools and Factsheets

Revised AQFS Mission: To ensure the quality and safety of California Almonds, through science, research, leadership and industry-wide education

Everything You Want to Know About Retaining Almond Crunch and Flavor

- Dr. Fanbin Kong, University of Georgia 12:30 --1:00pm
 - Impact of storage conditions on physical properties of almonds
- Dr. Alyson Mitchell, University of California, Davis 1:00 – 1:30pm
 - The Chemistry of Rancidity in Almonds
- Drs. Ellie King and Dawn Chapman, The National Food Laboratory 1:30 – 2:00pm
 - Profiling Sensory Differences in Almond Varieties
- Dr. Ron Pegg, University of Georgia 2:00 – 2:30pm
 - Shelf-life of Nonpareil Almonds: Chemical and Textural Attributes and Their Association with Consumer Rejection

THE CRUNCH THAT KEEPS YOU IN THE GAME

©2015 California Almond Board. All rights reserved. Almonds are a natural source of Vitamin E, Magnesium, Calcium, Potassium, and Fiber. Almonds are also a good source of Monounsaturated Fat, Protein, and Biotin. Almonds are a healthy snack for everyone. For more information, visit www.almonds.com.

There's extended playtime in the crunch of almonds. And for most, big energy-boosting power. 4g of hunger-fighting fiber and essential nutrients in every heart-healthy, one-ounce handful.

Learn more at Almonds.com.

Almonds are a natural source of Vitamin E, Magnesium, Calcium, Potassium, and Fiber. Almonds are also a good source of Monounsaturated Fat, Protein, and Biotin. Almonds are a healthy snack for everyone. For more information, visit www.almonds.com.


©2015 California Almond Board. All rights reserved.

 **california almonds**
CRUNCH ON



A close-up photograph of several green almonds on a branch, with vibrant green leaves. The background is softly blurred, showing more of the tree and a hint of a person in the distance. The lighting is bright and natural, highlighting the texture of the almond skins and the freshness of the leaves.

**Fanbin Kong,
University of Georgia**



Impact of Storage Conditions on Physical Properties of Almonds

Fanbin Kong, University of Georgia

Li Taitano, RF Biocidics

R. Paul Singh, University of California, Davis

Quality deterioration of almonds

- Mode of deterioration:
 - Rancidity due to lipid oxidation
 - Loss of crispness due to moisture absorption
 - Microbial growth
- Critical environmental factors
 - Temperature
 - Relative Humidity
 - Oxygen




Water activity

- Water activity (a_w) is defined as the vapor pressure of water above a sample (p) divided by that of pure water at the same temperature (p_0),

$$a_w = \frac{P}{P_0}$$

- Water activity of food affect microbial growth as well as the rate of chemical and physical deteriorative reactions.
 - microbial growth occur at $a_w > 0.6$.
 - lipid oxidation occurs below $a_w > 0.30$.
 - Maillard browning reaction accelerates as the $a_w > 0.25-0.3$.




Reaction rates in foods as a function of water activity

Moisture migration

- The difference between the relative humidity (RH) of the surrounding environment and water activity (a_w) of the food determines whether a food gains or loses moisture during storage
 - $RH > a_w$, food will absorb moisture from air
 - $RH < a_w$, food will lose moisture
 - At equilibrium, $RH = a_w$




Air (RH)



Almond
(a_w)

Adsorption isotherms

- The extent of moisture migration can be described by adsorption isotherms
 - the amount of water on the food material as a function of its water activity at constant temperature.
- Various empirical mathematical models are developed to describe the sorption isotherms



Effect of temperature

- Increasing temperature generally increases the rate of chemical reactions
 - result in faster deterioration.
- The rate of water absorption increases at high temperature
 - due to increased diffusivity coefficient
- Storage losses under fluctuating temperature condition can be significantly greater than that at the constant average temperature



Objectives of our research


- How change of ambient temperature affect temperature of almonds packed in a cardboard box;
- How temperature and relative humidity affect moisture migration in almonds and their texture
 - Determine moisture adsorption isotherms of almonds
 - Measure almond texture
- Develop predictive modeling to estimate the temperature changes and texture of almonds during transportation and storage.



California grown varieties

Nonpareil	Np: Nonpareil Pasteurized
	Nup: unpasteurized
Monterey	Mp: Pasteurized
	Mup: unpasteurized
	Mb: blanched
Carmel	Cp: Pasteurized
	Cb: blanched
Butte	unpasteurized

Temperature measurement



Storage device

- Storage jars holding almonds and different saturated salt solutions in the incubator
- The weight of almonds at different equilibrium relative humidities and temperatures were measured until samples reached equilibrium moisture content



*Experimental apparatus for the adsorption isotherms
(Thymol used for $a_w > 0.7$)*

Storage conditions

- Temperatures: 7, 25, 35, 50 °C
- Relative humidity (RH) range: 11%~97% by nine different saturated salt solutions
- Corresponding water activity (a_w) is obtainable from the RH according to

$$a_w = \frac{RH}{100}$$



Instruments

- Determination of almond thermal properties: density, thermal conductivity, specific heat capacity, thermal diffusivity



Kd2 Pro Thermal Properties Analyzer



Mettler-Toledo Differential Scanning Calorimeter(DSC)

Instruments



*Low-Temperature
Incubator Model 815*



*Aqualab CX-2
Water Activity Meter*




TA.XT2 Texture analyzer

Measurement of textural properties

I. Compression test




II. Three-point bending test



III. Penetration test




IV. Cutting test by using a craft knife



Penetration test

- Firmness (N): The maximum force in the curve was used to indicate the hardness of the almond;
- Fracturability (mm): The linear distance of the curve;
- Toughness (N.mm): The area under the curve;
- Stiffness (N/mm): The gradient of the first force peak;
- Deformation (mm): The distance at the first peak.



Mathematical models

- Kinetic model (Fick's second law)
 - to predict moisture changes of almonds with time at different temperatures and water activities
- Sorption isotherm model (GAB model)
 - to correlate the data of equilibrium moisture of almonds and the water activity
- Textural Model (Fermi's distribution)
 - to describe textural changes of almonds at different water activities and temperatures

Predictive modeling

- Develop a model to predict temperature changes in packaged almonds in response to ambient temperature
- Develop a model to predict textural changes in almonds under constant and dynamic storage conditions





Results



25 lbs cardboard box with plastic liner



Ambient temperature from 3 °C to 21 °C



- T1 reached 10, and 15 °C after 11 and 17 hours
- T2 reached 10 and 15 °C after 20 min, and 3 hours





25 lbs cardboard box with plastic liner

Ambient temperature from 3 °C to 35 °C





- T₁ increased to 10, 20 and 30 °C after 7, 12, and 24 hours
- T₂ increased to 10, 20 and 30 °C after 20 min, 2 hour, and 12 hours

Experimental and Predicted Moisture Content in Almonds during storage.





Moisture adsorption isotherm of almond



Experimental and predicted data of equilibrium moisture content (EMC) of Nonpareil almonds (lines correspond to the GAB model)


Texture analysis



Representative Force-Distance curves obtained from penetration test of Monterey almonds stored at 25°C

Predictive modeling of almond texture

<http://rpaulsingh.com/abc/index.html>




Input

Variety: Nonpareil
Type: pasteurized
Temperature: 25° C
 a_w : 0.65
Storage period: 25 day
Initial m_c : 0.035
kg water/kg solid

Output

After storage 25 days, the predictive moisture content is 0.0605 kg water/kg solid;
Predictive firmness is 32.2 N, range from 27.3 N to 37.1 N;
Predictive fracture force is 25.7 N, range from 22.5 N to 29.0 N;
Predictive toughness is 60.3 N.mm², range from 46.7 N.mm² to 73.9 N.mm²;
Predictive stiffness is 34.5 N/mm², range from 25.7 N/mm² to 43.8 N/mm².



<http://rpaulsingh.com/abc/index.html>


Input

Variety: Nonpareil
Type: pasteurized

I. Temperature: 25° C; a_w : 0.65;
Storage period: 25 day; Initial m_c :
0.0350 kg water/kg solid.

II. Temperature: 35° C; a_w : 0.75;
Storage period: 20 day; Initial m_c :
0.0605 kg water/kg solid.

III. Temperature: 40° C; a_w : 0.85;
Storage period: 20 day; Initial m_c :
0.0755 kg water/kg solid.



<http://rpaulsingh.com/abc/index.html>

Conclusion

- Moisture sorption isotherms were developed for major California almond varieties
- Texture of almonds at different EMC were determined
- Temperature changes of packaged almonds were measured as affected by ambient temperature and packaging dimensions
- An online Adobe Flash model was developed
 - predict how storage humidity and temperature could affect almond moisture and texture
- Ongoing studies
 - developing computational modeling to predict temperature changes in packaged almonds



Thank you for your attention!

Questions?



**Alyson Mitchell,
UC Davis**

The Chemistry of Rancidity in Almonds




*Alyson Mitchell PhD, Food Science Department,
University of California Davis*


The Almond Conference
Almond Quality Workshop
Dec 9th, 2014
Sacramento CA

What is Almond Oil?

- Almonds are composed of about 51-60% oil
 - Varies depending upon the cultivar




- Almond oil is composed of triglycerides
 - A triglyceride is 3 fatty acid molecules attached to a molecule of glycerol



Lipid Composition of Almond Oil

- Fatty acids can be saturated (no double bonds) or saturated (double bonds)




Saturated fat

Monounsaturated fat

Polyunsaturated fat


- The primary fatty acids in almonds are:

Name	Number of Carbons:Double bonds	Percent in Almond Oil
Oleic	18:1	60-75%
Linoleic	18:2	19-30%
Palmetic	16:0	0.5-8%
Stearic	18:0	1-3%




Rancidity

- Rancidity is the unpalatable odor and flavor of deteriorating edible fats and oils in foods
- Rancidity occurs via two chemical reactions:
- Oxidation
 - Oxygen attack of the triglycerides
- Hydrolysis
 - Addition of *water* across triglycerides and release of Fatty acids (FFAs)



Scheme 1. Over-all reaction scheme for (I) oxidative and (II) hydrolytic rancidity

Oxidative Rancidity: *Three Phase Process*



1. Initiation Phase

- Molecular oxygen combines with unsaturated fatty acids to produce hydroperoxides and free radicals
- Requires an initiator (e.g. heat, light, metals, enzymes, etc.,)

2. Propagation Phase (autoxidation phase)

- The reactive products of the initiation phase react with additional lipid molecules to form new reactive lipids

3. Termination Phase

- Lipid radicals react with each other or breakdown to form relatively unreactive compounds including aldehydes and ketones (volatile odors)

Rancidity in Almonds



- Rancidity in almonds occurs primarily via the oxidation of oleic [18:1] and linoleic [18:2] acids
 - Initiated by exposure to heat (pasteurization, blanching, roasting, etc.), or oxygen exposure (e.g. during storage)
- Primary lipid oxidation products include:
 - Lipid peroxides and conjugated dienes
- Secondary lipid breakdown products include:
 - Volatile compounds (aldehydes, ketones, off-odors)
 - Non-volatile compounds (degradation products, off-flavors)

Measuring Rancidity



- Although rancidity is one of the most pressing problems confronting processors, there is no completely objective chemical method for determining rancidity
- Industry relies on several analytical methods for routine estimates of oxidation in almonds however, there is no uniform or standard method for detecting oxidative changes
- The biggest challenge:
 - Lipid oxidation is a dynamic process and levels of chemical markers of lipid oxidation change throughout the lipid oxidation process
 - Each method measures something different

Chemical Measures

moving analytical targets




I. Oxidative Rancidity:

- Peroxide Value (PV)

- Lipid peroxides are the first product of oxidation and are used as an indicator of the early oxidative changes
- Measures initial stages of rancidity
- Almonds PV < 5 meq/Kg is considered the benchmark

- However:

- PV levels decrease as oxidation progresses as lipid peroxides break down
 - Low levels can be present when there is extensive lipid oxidation



Lipid peroxide

Peroxide Values in Aged CA Almonds

Monterey (raw) meq/kg of oil	Nonpareil (raw) meq/kg of oil	Fritz (raw) meq/kg of oil	Butte (roasted)* meq/kg of oil
0.577 ± .192	0.788 ± 0.088	0.738 ± .171	6.715 ± .133

- All samples were in refrigerated storage for 24 months before analysis
- *Aged samples were roasted at 190 C for 13 minutes, and analyzed within 48 hours
- Based upon triplicate analysis

PV < 5 meq/Kg

Chemical Measures

moving analytical targets




- **Conjugated Dienes (CDs)**

- Measures *initial stages* of rancidity

- When polyunsaturated fatty acids are oxidized, they rearrange to form CDs
- CDs absorb UV light at 232–234 nm which can be measured
- The oxidation of linoleic acid is being measured in almonds

- However:

- CD levels can decrease as oxidation progresses (decompose)



Conjugated Diene Levels in Aged CA Almonds

Monterey (raw)	Nonpareil (raw)	Fritz (raw)
0.197 ± .001	0.166 ± 0.001	0.181 ± .001

- All samples were in refrigerated storage for 24 months before analysis
- Based upon triplicate analysis
- No significant difference between the groups

- No common industry standard exists for CD values in almonds

Chemical Measures

moving analytical target



- **Almond Volatiles**

- Measures the later stages of oxidation
 - Lipid peroxides breakdown to form many volatile compounds
 - Generated during roasting for flavor

- **Hexanal**

- Most commonly measured secondary product of lipid oxidation
- No common industry standard for hexanal in almonds
- A wide range of volatile compounds exist in raw, roasted, and stored almonds

Chemical Measures

moving analytical targets



II. Hydrolytic Rancidity:

- **Free Fatty Acids (FFA):**
 - Triglycerides hydrolytically breakdown into FFAs
 - Reported as % by mass of free fatty acids expressed as oleic acid
- For almonds the industry standard is $< 1.5\%$ FFAs
 - Found to correlate with sensory evaluation in butter
 - No studies in almonds

Free Fatty Acid Levels in Aged CA Almonds




Monterey (raw) % Oleic	Nonpareil (raw) % Oleic	Fritz (raw) % Oleic	Butte (roasted)* % Oleic
0.084 ± .007	1.721 ± 0.078	0.054 ± .003	0.106 ± .001

- All samples were in refrigerated storage for 24 months before analysis
- Samples were analyzed in triplicate
- *Aged samples were roasted at 190 C for 13 minutes and analyzed within 48 hours

Measuring Volatiles in Almonds



- Limited research available on the composition of volatiles in raw and roasted almonds
 - Takei et al., 1974
 - Solvent extraction
 - L. Vazquez-Araujo, et al., 2008, 2009
 - Simultaneous steam distillation extraction
- Limited information on volatiles changes during storage
- Over the past 3 years we have developed sensitive GC/MS methods for measuring almond volatiles and characterized them in raw, roasted and stored almonds



Experimental Design

- Measure the impact of roasting and storage on volatile composition
- Early markers of rancidity development
 - *Prunus dulcis* cv. Butte/Padre
 - Dry roasting temperature: 138°C
 - Roasting Time: 28 min, 33 min and 38 mins
- Storage Conditions
 - Temperature: 35°C
 - Humidity: Ambient and 65% RH
 - Time: Evaluated at 0, 2, 4, 6, 8, 10, 12, 16, 20, 24 weeks
- Analysis:
 - Headspace solid-phase micro-extraction (HS-SPME)
 - *No solvents, heat or artifact generation*
 - GC/MS



Sample Preparation



- Preparation: Cold room at 4°C
 - 50 g almonds were homogenized
 - Sifted through a 16 meshes screen for particle size control
 - 5 g was transferred to a 20 mL headspace vial
 - 100 ml internal standard (500 ppb) added and the vial was sealed
 - All samples were prepared in triplicate



Headspace solid-phase microextraction (HS-SPME)




- Sample in the vial was equilibrated for 30 minutes
- Exposed to a 1 cm 50/30 μm coated fiber for 30 min at room temp
- Desorption (230°C): 10 min in injection port



GC Chromatogram of Almond Volatiles





- Peak Identification:
- Comparison of mass spectra and t_R with standards (38) or by comparing MS and Kovats Index with NIST MS database with 80 % cut-off (no standard)




Volatiles Identified in Raw Almonds



- Identified 41 Compounds:
- 3 carbonyls, 1 pyrazine, 20 alcohols, and 7 additional volatiles
- Benzaldehyde, the breakdown product of amygladin, was the predominant volatile in raw almonds ($2,934.6 \pm 272.5$ ng/g)
 - Almond-like aroma
- Hexanal (422.6 ± 97.9 ng/g); found in other nuts as well
 - Fruity/green (cut grass)
- 2-phenylethanol (6.2 ± 0.6 ng/g); deamination of amino acids in plants
 - Floral
- α -Pinene (15.0 ± 0.1 ng/g) and limonene (16.6 ± 0.5 ng/g); terpenes
 - Pine/citrus



Volatiles in Roasted Almonds



- **Roasting:** an additional 13 volatiles were formed during roasting
 - Most related to flavor: pyrazines, branch-chain aldehydes, alcohols, heterocyclic and sulfur containing compounds
 - Maillard reaction products
 - Some lipid oxidation products
- **Storage:** an additional 17 new compounds, absent in raw and freshly roasted almonds, but detectable after 10-16 weeks of storage were identified
 - Lipid oxidation products
 - ketones, aldehydes, alcohols, oxiranes and short-chain acids


Changes in Volatile Aldehydes and Keytones

possible compounds	roasting time				increase ^b (%)
	raw	28 min	33 min	38 min	
aldehydes and ketones					
butanal	19.6 ± 2.7	27.6 ± 1.5*	29.3 ± 0.6*	40.8 ± 2.1***	67
2-methylbutanal [chocolate/nutty]	14.3 ± 0.3	1468.6 ± 25.7**	5000.3 ± 241.1***	6573.7 ± 275.0***	30216
3-methylbutanal [chocolate]	32.4 ± 0.5	911.4 ± 50.9*	2867.4 ± 71.1***	4268.9 ± 381.8***	8167
2,3-butanedione [sweet/butter]	8.0 ± 0.3	100.3 ± 0.8***	163.7 ± 1.3***	226.3 ± 13.7***	1940
pentanal	50.4 ± 5.7	223.0 ± 8.6***	169.0 ± 5.1***	264.1 ± 15.9***	334
hexanal	422.6 ± 97.9	983.0 ± 133.7**	689.0 ± 78.1	1140.8 ± 3.8**	122
2-heptanone	50.0 ± 4.7	72.0 ± 7.3*	71.0 ± 6.3*	123.6 ± 3.0***	78
heptanal	40.5 ± 8.9	75.2 ± 16.2*	57.1 ± 4.0	114.8 ± 3.0**	103
2-hexenal [almond/green leaf]	ND ^c	14.6 ± 2.7**	11.3 ± 2.2	14.1 ± 2.7**	New
2-methylxolan-3-one [rummy/nut]	ND	15.4 ± 1.3	86.3 ± 4.2	128.1 ± 11.0	New
3-hydroxybutan-2-one [buttery]	ND	2.2 ± 0.2	3.0 ± 0.1	3.8 ± 0.6	New
octanal	25.2 ± 4.7	31.1 ± 7.3	18.5 ± 6.3	42.0 ± 3.0	21
1-hydroxypropan-2-one	1.3 ± 0.0	9.0 ± 0.9*	11.0 ± 0.0**	13.7 ± 3.0**	771
(Z)-2-heptenal	19.1 ± 0.9	65.6 ± 13.2**	36.5 ± 4.6	61.9 ± 1.6**	186
nonanal	36.6 ± 4.9	55.9 ± 13.3	34.6 ± 4.0	70.5 ± 18.9	47
(E)-2-octenal	7.3 ± 0.9	12.5 ± 2.1	8.3 ± 0.1	15.9 ± 2.0*	67
furfural [brown/caramel]	ND	103.2 ± 8.7	366.1 ± 13.2	460.0 ± 21.4	New
decanal [aldehydic]	ND	6.9 ± 2.3	5.0 ± 1.6	4.6 ± 1.0	New
benzaldehyde [almond/marzipan]	2934.6 ± 272.5	368.8 ± 41.2***	246.7 ± 53.0***	331.9 ± 65.4***	-89
(Z)-2-nonenal [green]	ND	ND	ND	5.3 ± 1.7**	New
2-phenylacetaldehyde [honey/floral]	ND	107.5 ± 20.3*	284.0 ± 22	491.3 ± 45.4***	New

- Generated through lipid oxidation and the Maillard reaction
- Most compounds increase with roasting (exception is benzaldehyde)

Changes in Volatile Pyrazines

Roasted Nutty Aromas





Compound	raw	roasting time			increase ^b (%)
		28 min	33 min	38 min	
<i>pyrazines</i>					
2-methylpyrazine	ND	4.1 ± 0.3*	21.5 ± 0.6***	26.5 ± 1.8***	New
2,5-dimethylpyrazine	11.4 ± 0.5	16.2 ± 0.6***	53.3 ± 0.3***	66.5 ± 0.4***	298
2,6-dimethylpyrazine	ND	ND	2.8 ± 0.4**	4.2 ± 0.6***	New
2-ethylpyrazine	ND	ND	2.6 ± 0.1***	3.2 ± 0.1***	New
2,3-dimethylpyrazine	ND	ND	1.0 ± 0.1***	1.4 ± 0.1***	New
2-ethyl-6-methylpyrazine	ND	ND	1.7 ± 0.1***	2.2 ± 0.0***	New
trimethylpyrazine	ND	ND	4.5 ± 0.3***	6.1 ± 0.2***	New

- Six new pyrazines were identified in roasted almonds
- Chocolate, nutty, meaty, roast flavors
- Generated through the Maillard reaction
- Most have low odor thresholds and increased with the degree of roast

Decreases in Select Volatiles During Storage



Aldehydes and Keytones



- Levels of aldehydes were significantly higher immediately after roasting
 - These are products generated in response to thermal processing
 - nutty, caramel, chocolate aroma
- Levels decreased significantly (75-88%) over the first 4 weeks of storage
- Some aldehyde levels increase around 20 weeks of storage reflecting lipid oxidation

Decreases in Select Volatiles During Storage



Pyrazines (roasted almond flavor)



- The levels of 2,5-dimethylpyrazine and 2-methylpyrazine decreased slowly during 25 weeks storage
- Other pyrazines did not decrease significantly
 - Predominate aromas



Decreases in Select Volatiles During Storage

Additional Losses



- Decreases in compounds (4 weeks) relating to roasted almond flavor (1-methylthio-2-propanol) and fresh aroma (α -pinene), ethyl acetate (sweet)

Increases in Select Volatiles During Storage: Early Markers of Rancidity



- Levels of hexanal decreased initially, and began to increase again ~18 weeks (regardless of roasting temperature). Levels did not increase to above baseline until after 20 weeks
 - Hexanal is a product of the oxidation of linoleic acid
- Linear increases in heptanol and 1-octanol are observed at 16 weeks
- Heptanol has a greater response

Additional Markers of Early Changes

- Compounds that are initially absent in the roasted almonds but detectable after 16 weeks of storage
- Levels of 2-octanone, 3-octen-2-one, and acetic acid showed large increases as early as 16 weeks

volatile compounds	light roast (28 min at 138C)			dark roast (38 min at 138 C)		
	16 wk	20 wk	24 wk	16 wk	20 wk	24 wk
2-octanone	13.4 ± 1.4	52.3 ± 2.9	33.3 ± 0.1	6.4 ± 0.2	15.4 ± 0.9	34.2 ± 4.0
2-nonanone	9.8 ± 1.4	47.5 ± 0.9	31.2 ± 0.2	4.8 ± 0.3	16.4 ± 0.4	28.6 ± 4.3
3-octen-2-one	18.1 ± 1.8	41.1 ± 2.0	45.4 ± 0.9	9.1 ± 0.4	19.7 ± 0.6	33.6 ± 4.5
2-decanone	2.8 ± 0.2	13.4 ± 0.2	10.3 ± 0.4	ND ^a	7.2 ± 1.4	7.6 ± 1.3
(E)-2-decenal	2.9 ± 0.1	7.1 ± 1.1	10.9 ± 0.9	2.4 ± 0.8	5.6 ± 0.4	6.6 ± 1.4
2,4-nonadienal	10.5 ± 0.9	14.2 ± 1.2	15.4 ± 1.1	7.5 ± 0.1	10.9 ± 0.5	10.4 ± 1.6
2-undecenal	ND	2.1 ± 0.7	3.4 ± 0.3	ND	1.5 ± 0.1	1.8 ± 0.3
1-octen-3-ol	2.2 ± 0.2	7.4 ± 0.4	6.9 ± 0.1	1.4 ± 0.0	4.1 ± 0.0	8.9 ± 1.3
nonanol	0.8 ± 0.1	2.2 ± 0.1	2.0 ± 0.1	0.5 ± 0.1	1.1 ± 0.3	1.0 ± 0.1
pentyl oxirane	9.9 ± 0.8	55.8 ± 11.1	27.8 ± 0.9	5.0 ± 0.8	9.5 ± 0.4	97.5 ± 9.3
hexyl oxirane	31.0 ± 3.1	1.7 ± 0.7	42.1 ± 0.2	9.7 ± 1.5	12.2 ± 0.6	2.9 ± 0.3
acetic acid	35.8 ± 2.7	60.8 ± 3.0	45.2 ± 2.3	43.5 ± 5.4	57.9 ± 1.5	60.2 ± 16.1
vinyl hexanoate	1.5 ± 0.2	6.8 ± 0.1	4.9 ± 0.2	1.2 ± 0.0	4.1 ± 0.4	8.1 ± 1.3
pentanoic acid	0.9 ± 0.1	6.1 ± 0.2	2.5 ± 0.2	0.5 ± 0.1	3.3 ± 0.0	5.9 ± 1.9
heptanoic acid	0.6 ± 0.0	5.4 ± 2.3	4.6 ± 0.4	0.5 ± 0.1	4.1 ± 0.7	2.7 ± 0.6
octanoic acid	0.4 ± 0.1	5.2 ± 2.3	5.1 ± 0.7	0.2 ± 0.0	3.6 ± 0.7	2.0 ± 0.3
nonanoic acid	ND	1.3 ± 0.8	2.5 ± 0.2	ND	0.6 ± 0.2	0.4 ± 0.0

^aND stands for not detected.

Conclusions

- Storage (35°C):
 - Significant decreases in aroma volatiles are observed by 4 weeks of storage
 - independent of the roasting time and storage temperature
 - Oxidation occurs at 16 weeks of storage
 - Oxidation products began dominating the profile by 20 weeks
- Potential markers of early oxidative changes:
 - 1-Heptanol (and 1-octanol) as these compound compounds demonstrate robust linear changes in concentration at 16 weeks versus 20 weeks for hexanal
 - Compounds absent from raw and freshly roasted almonds but detectable ~16 weeks of storage (2-octanone, 3-octen-2-one, and acetic acid)

Acknowledgements

Advancing Knowledge a Team Effort

- UC Davis
 - Gong Zhang, PhD
 - JiHyun Lee, PhD
 - Lu Xio, MS
 - Cristian Rogel Castillo, PhD student
 - Lily Franklin, MS student
 - Tom Gradziel, PhD
- Food Safety and Measurement Facility
 - Susan Ebeler, PhD
 - Tomas Collins, PhD
- Almond Board of California
 - Guangwei Huang, PhD
 - Robert Curtis, MS
 - Karen Lapsley, PhD
- Agilent Technologies
 - Jerry Zweigenbaum, PhD



Ellie King and Dawn Chapman, National Food Laboratory





THE
NATIONAL
FOOD
LAB



Profiling Sensory Differences in Almond Varieties

Dr Dawn Chapman & Dr Ellie King
The National Food Lab, Livermore CA



Content

- Capabilities of The NFL
- Methodology – Consensus Rating Evaluation
- Results
- Key Findings





What We Do

The NFL is a food and beverage consulting and testing firm providing creative, practical and science-based solutions for the following areas:

Product and Process Development

Safety and Quality

Sensory and Consumer Research

Sensory Evaluation

Our Approach:

- Tap into our pool of 45 highly trained panelists with an average of 5 years of experience.
 - These are not Consumers and they do not provide their liking or opinions.
 - Skilled at describing sensory characteristics and intensity ratings of a wide variety of products.
 - Screened for olfactory & gustatory acuity and ability to describe flavor nuances.
 - Extensively trained for 3+ months before qualification.
- Overseen by experienced panel leaders
 - Advanced degrees (Master's or Ph.D. in Sensory Science)



Sensory Evaluation



Evaluation Methodologies:

- Discrimination testing
- Quantitative descriptive evaluation
- Narrative descriptive analysis
- Consensus rating evaluation

Applications:

- Product understanding
- Quality assessments
- Sensory specifications
- Panel training /terminology training
- Shelf life studies

Methodology: Discrimination Testing



Experimental design:

- Twenty-thirty trained panelists participated in the study.
- Panelists individually assess each sample.
- Panelists indicate differences or similarities between samples using various types of discrimination tests, such as Triangle Test and Ranking.
- Statistical analyses include Binomial Tests and Friedman's Rank Sum Test.

Sample presentation:

- All samples in a test are presented together.
- Samples are identified by random 3-digit numbers.

Methodology: Quantitative Descriptive Evaluation



Experimental design:

- Ten trained panelists participate in the study.
- Panelists participate in Orientation sessions to review samples.
- References are used to illustrate and define the sensory characteristics.
- Panelists individually rate each sample with at least two replications.
- Sensory attributes scored on 15-point scales.
- Statistical analyses include ANOVA and Means Comparisons.

Sample presentation:

- Samples are presented monadically (one at a time).
- Samples are identified by random 3-digit numbers.
- Samples are served in a balanced order (i.e., each sample will be seen approximately an equal number of times in each possible position).

Methodology: Narrative Descriptive Analysis



Experimental design:

- Three trained panelists participated in the study.
- Panelists individually assess each sample.
- Panelists verbally indicate the character and intensity of the major sensory characteristics of each samples through group discussion led by a panel leader.
- No statistical analyses are conducted on the narrative data.

Sample presentation:

- Samples are presented monadically (one at a time).
- Samples are identified by random 3-digit numbers.

Methodology: Consensus Rating Evaluation

– used to assess almond samples

Experimental design:

- Three trained panelists participated in the study.
- Panelists individually rated each sample.
- Sensory attributes scored on 15-point scales.
- The individual scores were verbally collected by a panel leader and were discussed to reach consensus scores.
- No statistical analyses were conducted on the consensus data.

Sample presentation:

- Samples are presented monadically (one at a time).
- Samples are identified by random 3-digit numbers.
- Approximately 10 nuts of each sample provided to each panelist in a white plastic bowl.
- Panelists rate appearance, then aroma, before tasting at least 3 nuts at once and rating texture and flavor attributes.

Raw Almond Samples

Almond varieties	Grade	Size
NPS	Supreme	25/27
Monterey	SSR	25/27
Butte	SSR	34/36
Carmel	SSR	27/30

Sensory Attributes*

Aroma/Flavor:

- Overall Aroma Intensity
- Overall Flavor Intensity
- Marzipan/ Benzaldehyde flavor
- Nutty (not benzaldehyde)/ Earthy flavor
- Hay flavor
- Woody/ Sawdust flavor
- Sweet taste
- Bitter taste

Texture/Mouthfeel:

- Hardness
- Fracturability/ Brittle
- Deformability/ Spongy
- Chewy
- Crunchy -1st bite
- Moistness
- Cohesiveness of Mass
- Astringency

* Modified from the work conducted by Prof Hildegard Heymann at UC Davis in 2013.

AROMA/FLAVOR:

Total Aroma Intensity



Total Flavor Intensity



Marzipan/ Benzaldehyde



Nutty (not Benzaldehyde)/ Earthy



Hay



Woody/ Sawdust



Sweet



Bitter



Results – Means Table


- Means Table reports the intensity ratings of each sensory attribute for each sample.

TABLE 1
CONSENSUS RATING EVALUATION OF RAW ALMOND VARIETIES
n=3 Panelists

	NPS	Monterey	Butte	Carmel		NPS	Monterey	Butte	Carmel
AROMA/FLAVOR:					TEXTURE/MOUTHFEEL:				
Overall Aroma Intensity	4.00	1.50	3.00	3.50	Hardness	4.50	5.00	6.00	3.50
Overall Flavor Intensity	4.50	5.00	4.50	4.50	Fracturability/Brittle	3.00	5.00	4.50	3.00
Marzipan/Benzaldehyde	3.00	4.00	1.50	3.00	Deformability/Spongy	2.00	3.00	1.00	2.50
Nutty (not Benzaldehyde)/Earthy	3.00	2.00	3.50	3.00	Chewy	4.00	4.00	1.00	4.00
Hay	1.00	1.00	2.00	2.00	Crunchy - 1st bite	3.00	3.50	5.00	3.50
Woody/Sawdust	0.50	1.00	2.50	1.00	Moistness	3.00	3.00	2.00	4.00
Sweet	0.50	1.50	0.50	1.50	Cohesiveness of Mass	4.50	3.50	2.50	1.50
Bitter	2.50	2.00	1.50	2.00	Astringency	2.00	2.50	3.50	3.00


Results – Aroma/Flavor Profile

- All raw almond varieties have different flavor profiles.
 - NPS has a high Overall Aroma Intensity and Sweet taste.
 - Monterey has a high Overall flavor intensity, with high Marzipan/Benzaldehyde flavors and a slight Bitter taste.
 - Butte is high in Nutty/Earthy, Hay and Woody/Sawdust flavors.
 - Carmel has a similar flavor profile to NPS, but with higher Hay flavors and Bitter taste.



Results – Texture Profile

- All raw almond varieties have different texture profiles.
 - NPS has an intermediate texture profile with a high Cohesiveness.
 - Monterey is Brittle, Spongy and Chewy.
 - Butte is Hard, Crunchy and Astringent.
 - Carmel is the Softest, Moistest and Crumbliest.



Key Findings

- The sensory profiling method can be used to quantify intensity differences in sensory attributes among almond samples.
- These sensory differences can then be translated and presented to Food Manufacturers and Retailers, to aid discussions around which almond products would best serve the purposes of the end-product.



Next Steps – Product Landscape[®]

Next Step

- Another step in analyzing the sensory profile of almonds is to determine Consumer preference.
- The NFL performs **Product Landscape**® analysis – a combination of descriptive sensory and Consumer Testing with multivariate data analyses.

Product Landscape® In Action

When to use this tool...

- Understand competitive space/category
 - New to space
 - New product opportunities
- Uncover reasons behind performance issues
- Address competitive pressures
- Strategically target position in crowded space

What you will learn...

Product Development Insights

- Uncover attributes that most strongly impact liking
- Identify specific sensory-driven optimization direction

Marketing/Consumer Insights

- Define product opportunity areas/white space
- Determine if product delivers against key benefits
- Identify sensory cues linked to key product benefits

Product Landscape[®] Methodology

INPUT

Thoughtful Sample Selection

Descriptive Testing

Consumer Testing

Consumer Benefits

Product Analytics

DATA MINING

Consumer Liking Segments

Key Sensory Drivers

Joint Multivariate Analysis

Benefits/ Attitudes

OUTPUT

Identify Segments

(groups of consumers with different liking patterns)

- Within each segment...
- Which products are liked?
- Which sensory attributes drive product liking?
- Which sensory attributes are linked to benefit/ attitude cues?


Contributors



Guangwei Huang
Associate Director, Food Research & Technology
Almond Board of California

Dawn Chapman, Ph.D.
Technical Director, Sensory & Consumer Science
The National Food Lab
ChapmanD@TheNFL.com, 925-551-4243

Ellie King, Ph.D.
Project Leader, Sensory Science
The National Food Lab
KingE@TheNFL.com, 925-551-4289



**Ron Pegg,
University of Georgia**

Shelf-life of nonpareil almonds: Chemical and textural attributes and their association with consumer rejection

R.B. Pegg, D.R. Parrish, A.N. Cheely,
W.L. Kerr, and R.B Swanson



The University of Georgia



Objectives

1. To assess roasted and raw almonds stored in different temperature/humidity combinations by chemical, sensory, and textural means over 16 and 24 months, respectively.
2. To establish a lipid oxidation (rancidity) cutoff point linked to consumer acceptability.
3. To determine if packaging strategies (*i.e.*, choice of bags, N₂ flushing, environmental control) impact the shelf-life.
4. To determine the relationship between chemical indices and sensory evaluation of almonds under different storage conditions.
5. To identify and quantify oxidation volatiles over time, and to determine which volatiles and their levels trigger lack of product acceptability.



Importance of this Research

- Almonds are currently the largest specialty crop export in the U.S. (\$2.8 billion in 2011).
- Sales of products containing almonds grew \$236 million from 2008 to 2011.
- Almonds are ~50% oil by weight.
- Oleic (68%) and linoleic acids (28%) dominate.
- Almond storage is necessary!
- During storage, "off-flavors" develop as a consequence of unsaturated fatty acid oxidation.
- Rancidity is chiefly why almonds are rejected by consumers.



A close-up photograph of a glass jar filled with almonds. In the foreground, a small white dish contains a small amount of almond meal. The background is a warm, golden-yellow color.

Experimental Design

Sample Handling & Packaging

Table: Packaging of Nonpareil Raw and Roasted Almonds

	Raw	Roasted
Unlined Carton {UC} (600 ± 5 g)	X	
Polypropylene Bag {PP} (300 ± 5 g) ^a	X	X
High Barrier Bag {HBB} ^{b,c}		X

^a Bags were flushed with food-grade N₂ and sealed, providing a “pillow-pack” design. The headspace was analyzed in multiple samples, and the initial O₂ level was < 0.5%.

Loading Plan

It was hypothesized that (1) almonds stored at a higher temperature (T) and relative humidity (RH) will degrade most rapidly; and (2) roasted almonds will deteriorate quicker than raw samples. Samples were loaded in the order of their expected deterioration.

	Product	Raw		Roasted	
Load Day	Packaging	UC	PP Bag	PP Bag	HBB
Day X ^a	Storage Conditions	-40 °C			
Day G ^g		4 °C		4 °C	
Day F ^f		15 °C, RH = 50%			15 °C
Day E ^e		15 °C, RH = 65%			
Day D ^d		25 °C, RH = 50%			25 °C
Day C ^c		25 °C, RH = 65%			
Day B ^b		35 °C, RH = 50%			35 °C
Day A ^a		35 °C, RH = 65%			

^a November 26, 2012, ^b November 28, 2012, ^c November 30, 2012, ^d December 2, 2012, ^e December 4, 2012, ^f December 16, 2012, ^g December 18, 2012.



Sampling Plan

Samples stored under each T/RH condition were removed at 2 month intervals from the environmental chambers for assessment.



Breakdown of Sampling Plan

Day 1	Day 2	Day 3 (if sample "triggers" sensory)	Day 4	Day 5
Expeller-pressed Oil	Peroxide Value ^{a,d}	Roasted Trained Panel ($n = 6 \times 2$) ^e	Roasted Screening Panel ($n = 35$) ^f	Roasted Confirmatory Panel ($n = \sim 120$) ^g
Particle Size Reduction	Free Fatty Acids ^a	Raw Consumer Screening Panel ($n = 34-40$) ^g	Raw Confirmatory Panel ($n = \sim 120$) ^g	
Headspace Analysis ^b	Conjugated Dienes ^a			
Moisture Analysis ^b	TBARS ^a			
Water Activity ^b				
Texture Analysis ^c				

^aEvaluated with oil; ^bEvaluated with ground sample; ^cEvaluated with whole almonds; ^dPeroxide value 2 meq active O₂/kg oil; ^eTrained panel only for Roasted Samples, ^fScreening panel only necessary if roasted samples are deemed unacceptable to the trained panel, but not conclusively ^gConfirmatory panel for "triggered" raw samples and roasted samples that are deemed unacceptable to the screening panel.

Expeller-pressed Oil

- Oil is recovered with a Carver press and transferred to 20-mL amber vials, which are then N₂ flushed and stored at 4 °C until the next day.



Sample Preparation


Ground almond test samples are evaluated by headspace analysis (GC-SPME-FID and GC-SPME-MS), water activity (a_w), and moisture content.



Whole almonds are evaluated using a texture analyzer.



Methods for Chemical Testing



Free Fatty Acid Value:

Free fatty acids are said to be free when they are no longer esterified to glycerol.

Free fatty acids accelerate oxidation.


Expressed in percent as oleic acid.



Moisture Content and Water Activity:

Moisture accelerates oxidation.

Free water in a system (*i.e.*, a_w) is a better measure of H_2O effects on oxidation.



Spectrophotometric Determination of Conjugated Dienoic Acids:

CDs are more prone to form free-radical species that lead to ROOH formation.

Measured using a spectrophotometer at a_{233nm} and reported as absorptivity




Peroxide Value:

ROOHs are the main initial (primary) products of autoxidation.

PV is based on the ability to liberate I_2 from KI.

Expressed in terms of milliequivalents of active O_2 per kg fat.






2-Thiobarbituric Acid Value Direct Method:

Oxidative products (reported as MDA eq.) produce a color reaction with 2-TBA that is measured at 530 nm.

Used to measure secondary oxidation products of autoxidation.


Vitamin E Analysis

- Beginning on month 8, the tocopherol profile of almond lipids were determined.
- α -Tocopherol quenches radical oxygen species, so tracking vitamin E over time could help determine the overall oxidation mechanism.



Method for Texture & Sound Analysis

- Texture analysis was performed using a Texture Technologies TA-XT2i texture analyzer.
- The fracturability of whole almonds was evaluated using the texture analyzer with a compression disk.
- The audio was recorded during texture analysis and will be analyzed to provide a more complete fracturability profile.



Consumer Sensory Testing

Screening ($n = 35-40$) and confirmatory ($n = \sim 120$) panels

9-Point hedonic scale

Odor

Flavor

Texture

Overall acceptability

Rejection question

Response to ...

"if you had purchased this product, would you eat it?"

Product Code Number: _____ Panelist Number: _____

Almond Sensory Scorecard

You will evaluate XX samples today, each presented in a closed container. Please check the box (☐) that best reflects your opinion of this sample

Before tasting, evaluate the odor of the product. Hold the cup close to your nose and gently lift the lid as you take three short sniffs.

Odor

☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

Extremely Dislike Extremely Like

Eat the almonds and evaluate texture, flavor and overall acceptability by marking the box (☐) that best reflects how much you like this product

Texture

☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

Extremely Dislike Extremely Like

Flavor

☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

Extremely Dislike Extremely Like

Overall Acceptability

☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐

Extremely Dislike Extremely Like

Please drink water and eat some crackers and/or carrot to cleanse your mouth

Turn-over and complete the back

Descriptive Plan Roasted Almond Sample Training

Timeline for training panels^a

Prescreening Session ^b	Description
1	12 participants were prescreened resulting in 8 panelists to be trained
Training Sessions ($n = 6-8$)^{cd}	
1	Introduction to descriptive panel and scaling concepts
2	Texture- Hardness, crunchiness
3	Texture- Hardness, crunchiness
4	Flavor attributes- learning universal intensity and sweetness scales
5	Universal intensity scale, sweetness, and introducing fat oxidation- rancid (odor)
6	Cardboard, rancid, painty (odor and flavor)
7	Cardboard, rancid, painty (odor and flavor)
8	Relating previously discussed attributes to nuts
9	Relating previously discussed attributes to almonds
10	Overall almond intensity; establishing method and protocol for individual assessment
11	Running mock panels and troubleshooting; finalizing methods for individual assessment
Calibration/Refinement Testing ($n=6$)^{ef}	
3 sessions	Groups of 2-3; mock panels with short reviews of topics previously discussed

^aConstant reviewing throughout each session of previously discussed subject; ^bContact hours = 9 h; ^cFinal panel has 6 participants— Two panelists were released due to scheduling conflicts; ^dContact hours = 28 h; ^eCalibration panels were continued until means \pm SD were within acceptable range; ^fContact hours = 24 h.


Universal Intensity Reference

Soda in premium cracker	Grape in Kool-aid	Orange in Minute Maid OJ	Grape in Welch's grape juice	Cinnamon in Big Red gum
-------------------------	-------------------	--------------------------	------------------------------	-------------------------

2 4 7 10 12

Descriptive Panel

Odor and Flavor Attribute Intensity Evaluation



0
Not
Perceptible

15
High
Intensity

Almond Scorecard

Date: _____

PANELIST #: _____

Directions:

- Place one almond at a time between the molars; bite through once; evaluate for hardness. Continue to chew sample and evaluate for sweetness.
- Mark an X on scale along with product number.

Hardness- use hardness reference card

0
Not
Perceptible

15
High
Intensity

Sweetness- no reference needed

0
Not
Perceptible



15
High
Intensity

PLEASE FLIP OVER SCORECARD

Descriptive Panel

Texture Attribute Intensity Evaluation

Crunchiness



Hardness



Directions:

- Place one almond at a time between the molars; bite through once; evaluate for hardness. Continue to chew sample and evaluate for sweetness.
- Mark an X on scale along with product number.

Hardness- use hardness reference card



Sweetness- no reference needed



PLEASE FLIP OVER SCORECARD

Findings as of 18 mo

- In order to fail, samples must have a rejection rate $\geq 25\%$.
- At 18 mo, 13 samples have failed, and roasted is no longer being tested.

Raw	Roasted
2 mo → UC → 35 °C/65% RH	12 mo → PP → 35 °C/65% RH
6 mo → UC → 35 °C/50% RH	14 mo → PP → 35 °C/50% RH
6 mo → UC → 4 °C {RH > 90%}	16 mo → PP → 25 °C/65% RH
6 mo → PP → 35 °C/65% RH	16 mo → HBB → 35 °C
12 mo → PP → 35 °C/50% RH	
12 mo → UC → 25 °C/65% RH	
16 mo → UC → 25 °C/50% RH	
16 mo → UC → 15 °C/65% RH	
16 mo → PP → 25 °C/65% RH	

Findings as of 22 mo

- In order to fail, samples must have a rejection rate $\geq 25\%$.
- At 22 mo, 4 samples have yet to fail.


Raw	Overall Acceptability (n=38)
Baseline	6.0%
PP → 25 °C/50% RH	10.5%
PP → 15 °C/65% RH	15.8%
PP → 15 °C/50% RH	13.2%
PP → 4 °C {RH > 90%}	7.9%

Rejection Question:

If you had purchased this product, would you eat it?

Baseline Consumer Data: Sensory Raw Almonds (n = 118)

Raw almond baseline sensory panel



Rejection Question:
 If you had purchased this product, would you eat it?

 5.98% - No


Panel profile for raw baseline (n = 118) of 118 participants: 78.4% were female and 75.9% were aged between 18 to 27 years.

	Daily	Several times a week	Several times a month	Once a month	Several times a year	Never
Consumption	Frequency (%)					
Nuts	19.0	35.3	28.4	10.3	6.0	0.9
Almonds	6.9	25.0	32.8	12.1	19.8	3.4




6 mo - Results for Rejected Raw Almond Sample in a PP Bag @ 35 °C/65% RH

Consumer sensory evaluation: Baseline vs. rejected sample



Chemical analyses: baseline vs. rejected sample





Rejection Question: If you had purchased this product, would you eat it?


5.98% 'No' at baseline; **27.2% 'No' at 6 months.**

6 mo - Results for Rejected Raw Almond Sample in a PP Bag @ 35 °C/65% RH

Baseline




6 mo-Texture Results for Rejected Raw Sample in a PP Bag @ 35 °C/65% RH



	35 65 6 months	Baseline Raw
■ Total area under the curve (g*s)	57700	63200
■ Number of Fractures	6.3	5.91
■ Force to First Fracture (g)	12100	13000
■ Distance to first fracture (mm)	1.24	1.19

Baseline Data: Sensory Roasted Almonds (n=119)

Roasted almond baseline sensory panel



Rejection Question:
 If you had purchased this product, would you eat it?
 4.00% - No

Panel Profile for roasted almond baseline (n= 119) of 119 participants 77.3% were female and 74.8% were aged between 18-27 years.



	Daily	Several times a week	Several times a month	Once a month	Several times a year	Never
Consumption	Frequency (%)					
Nuts	17.6	32.8	34.5	8.4	8.4	5.9
Almonds	5.0	22.7	38.7	15.1	16.8	1.7



12 mo - Results for Roasted Almond Sample in a PP Bag @ 35 °C/65% RH

Descriptive sensory evaluation: Baseline vs. 12 mo

The screening panel ($n = 36$) presented a rejection rate of 25.0%, and the subsequent consumer panel ($n = 101$) gave a rejection rate of 29.7%, indicating the sample has failed.



	Baseline Roasted	35 65% 12 mo
■ Peroxide	0	1.89
■ Conjugated Diene	1.85	2.17
■ Moisture Content	0.893	3.28
■ Water Activity	0.141	0.548

Attribute means on truncated 15-point lines (* = $p < 0.05$)

Roasted Almonds PE bag 35°C/65% RH

Analysis type	Effect on Consumer Acceptability
↑ PV	↑ Rancid odor/flavor
↑ Moisture	Δ Texture Characteristics
↑ a _w	Δ Texture Characteristics
↓ # of Fractures	Δ Texture Characteristics

Non-sensory data	
PV (meq. O ₂ /kg oil)	1.49±0.18
Moisture (%)	2.87±0.07
a _w	0.46±0.003
# of Fractures	10.2±4.78

8 mo









Non-sensory data	
PV (meq. O ₂ /kg oil)	1.84±0.022
Moisture (%)	3.80±0.31
a _w	0.53±0.006
# of Fractures	5.3±3.53

10 mo



Non-sensory data	
PV (meq. O ₂ /kg oil)	1.89±0.048
Moisture (%)	3.28±0.09
a _w	0.55±0.004
# of Fractures	4.1±1.45

12 mo

Descriptive (n=6)



12 mo - Results for Roasted Almond Sample in a PP Bag @ 35 °C/65% RH



Findings to Date

- Almonds stored at **higher Ts** are degrading more rapidly than counterparts at lower Ts.
- Almonds stored in the **unlined cartons (UC) at higher RHs** are absorbing more H₂O; this is negatively impacting textural properties and rancidity.
- For almond samples in unlined cartons, desirable flavor volatiles **decrease** with time giving rise to overtone carbonyl compounds; these are related to rancidity.
- The **texture** has proven to be extremely important to the rejection of samples.
 - The texture of raw almonds (**which showed no signs of oxidation**) stored in unlined cartons at 4 °C and without RH control was more like that of an undercooked bean rather than a crunchy almond.
- The early onset of lipid oxidation compounds impacting odor and flavor in almonds does not translate to consumer rejection.

N₂-flushed PP bags provide adequate storage for raw and roasted almonds up to 22 mo and 16 mo, respectively, at 25 °C/50% RH or below.

Acknowledgments

Almond Board of California

Guangwei Huang

Karen Lapsley



Questions?

